

Model 2305[™] Eco Cylinder Scale Base [PN: 2305-<u>150LB</u> or 2305-<u>68KG</u> (or <u>70KG</u>)]:

The Model 2305[™] Eco-Scale is assembled and calibrated at the factory, then partially disassembled for shipment. Some reassembly and set-up is required before the scale can be operated.

Base Anchoring, Installation & Wiring:

Step 1: Remove all parts from carton and inspect for damage – bent metal, broken wires, cracks in digital controller, etc. Any shipping damage must be reported **to carrier!**


Parts Bag contains:

- 1) 33" chain, 1) tool tray, & 6) 'S' hooks for cylinder restraint and tool hangers
- 1) black plastic strain relief & nut
- 1) Flat washer for anchor screw under load cell
- 3) leveling shims
- 3) masonry screws for mounting scale base to floor
- 1) silicone grease for sealing load cell to mounting socket


The customer must mount the digital controller, tool rack w/ cylinder restraint chains and hooks on the wall. The base *must* be leveled for accurate readings by placing shims under the base. *IMPORTANT*: Base *must* be anchored 5" from the wall to avoid interfering with the cylinder on the scale.

Step 2: Place the scale on a solid, dry, and even surface. Clear the area of all debris where the scale base will be anchored.

Step 3: Refer to 2305 anchoring, installation & wiring drawings below:







BOTTOM VIEW

Wire Color Code:

Green = + Signal White = - Signal Black = - Supply Voltage Red = + Supply Voltage Violet = Shield

See controller manual for rest of set-up and operating instructions.

Replacement Parts:

PN: 2305LC - Canister load cell for Model 2305